












Component List

1. 	Frame - 1 Pcs	5. 	Fender - 1 Pcs
2. 	Front Fork - 1 Pcs	6. 	Grip - 2 Pcs
3. 	Saddle - 1 Set	7. 	Bolt - 2 Pcs
4. 	Wheel - 2 Pcs	8. 	Bolt - 1 Pcs
		9. 	Fork crown - 1 Pcs
		10. 	Washer - 4 Pcs
		11. 	Wrench - 1 Pcs

WARNING

1. Do not overtighten wheels. Wheels should spin freely.
2. Do not use on roads or anywhere near automobiles.
3. Use only on level ground. The run bike is not equipped with brakes.
4. Rider may not exceed 40Kg.
5. Rider must wear a helmet.
6. Do not use after dark. The run bike is not equipped with reflectors or lights.
7. Children must have adult supervision during use.
8. Ensure seat knob is tight.

Weehoo Inc.
505 Violet Street
Golden CO 80401
866-297-6049
www.RideWeehoo.com

